




# OTP

## on-the-pipe powerband fuzz

## instruction diagram



**TREBLE**  
 active treble control  
 clockwise is boost, counter-clockwise is cut  
 12:00 is flat

**MIDDLE**  
 active middle control  
 clockwise is boost, counter-clockwise is cut  
 12:00 is flat

**BASS**  
 active bass control  
 clockwise is boost, counter-clockwise is cut  
 12:00 is flat


On (Orange LED)

**SIZZLE**  
 active upper-frequency harmonics control  
 clockwise is boost, counter-clockwise is cut  
 12:00 is flat

**GAIN MODE TOGGLE**  
 (3 position)  
 M2 - high gain mode  
 X3 - extra gain and top end  
 M1 - low gain mode

**GAIN**  
 adjusts the distortion level

**VOLUME**  
 adjust to taste  
 unity gain is  
 approx 11:00



### ACTUAL SIZE

4 1/4" deep  
 3 1/4" wide  
 2" tall